



This guide covers surface mounted LED medicine cabinets. A separate guide is available for flush mount models.

TOOLS & MATERIALS REQUIRED

- Stud finder
- Hand-held Phillips screwdriver
- Wire stripper
- Pencil / marking tool
- Ammonia-free glass cleaner
- Level
- Drill & drill bits
- Voltage tester
- Goof-Off (original squeeze can)
- Licensed electrician (recommended)

UNBOXING & CARE

- 1 **Handle with care** when removing the cabinet from the packaging. Use **Goof-Off original squeeze can** (not spray) to remove any adhesive residue on the frame. Clean mirror surfaces with an **ammonia-free** window cleaner only.

ELECTRICAL REQUIREMENTS

- 1 Ensure the electrical supply is **Romex standard house wiring — 14/2 or 12/2** connected to a standard light switch. A wall switch connection is optional if the cabinet has an integrated switch.

■ *Dimmer wall switches are NOT compatible with LED medicine cabinets. The cabinet includes a built-in switch on the bottom — a dedicated wall switch is not required.*

- 2 Position the house circuit wiring at the **top center** of the installation area, approximately **2 inches from the top** of where the medicine cabinet will hang.

WALL BRACKET INSTALLATION

- 1 Install the **long mounting bracket** on the wall using the provided screws and self-drilling drywall anchors. Note: there is a channel within the top portion of the cabinet frame — the wall bracket slides into this channel.
- 2 **Carefully measure** the bracket location to ensure the cabinet will hang in the correct position.

■ *Do NOT use a power drill or electric screwdriver to install the drywall anchors or their screws. Use a hand-held Phillips screwdriver only — power tools will break the anchors or over-tighten the screws.*

ELECTRICAL CONNECTION



■ Turn off power to the circuit at the breaker panel before making any electrical connections.

- 1 With a partner holding the cabinet in position, connect the house wiring to the cabinet wiring:

Cable Color	Connect To	Function
Black	Black	Hot (Live)
White	White	Neutral
Green / Bare	Ground	Ground

- 2 Carefully hang the cabinet onto the wall bracket in the desired position. Restore power and test the cabinet lights.

ANGLE BRACKET INSTALLATION (BOTTOM)

- 1 Attach the angle brackets to the bottom of the cabinet by screwing the provided small screws into the two threaded holes.
- 2 Push the brackets flush against the wall and mark the wall anchor locations.
- 3 Remove the brackets and install the drywall anchors at the marked locations (hand screwdriver only — see warning above).
- 4 Re-attach the angle brackets and secure to both the wall and the cabinet. Once secure, install the glass shelves.

DOOR HINGE ADJUSTMENTS

Each hinge features three adjustment screws. Open the door to the indicated position before turning each screw.

Screw Position	Door Position	Adjusts
Center screw	Halfway open	Door height (up / down)
Closest screw	Fully open	Lateral position (left / right)
Furthest screw	Fully open	Door depth (in / out from wall)

For questions or additional support, call 937-810-0200 or visit mirrorsandmarble.com.